

Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
8G204	9G252	1	Gasket - extension	
8G205	10G199	2	Seal - oil	
8G208	10G198	5	Bush	
8G209	8G209SH	6	Pinion - speedometer	
8G210	9G212SH	7	Washer - joint - pinion bush	
8G211	9G213SH	8	Bush - pinion - nylon	
8G212	10G208	9	Seal - oil	
8G213	9G215SH	10	Ring - seal retaining	
8G214	8G214SH	11	Lever - change speed	
8G215	8G215SH	12	Peg - change speed lever locating	
8G216	8G216	13	Knob	
8G217	8G217	14	Nut - lock - 5/16" UNC X 1/2"	
8G218	8G218SH	15	Spring - anti-rattle	
8G219	8G219SH	16	Seat - top - change speed lever	
8G220	8G220SH	17	Seat - bottom - change speed lever	
8G221	8G221	18	Gasket	
8G222	FIX136	19	Screw - 1/4" UNF x 3/4"	
8G223	FIX156	20	Washer - spring - 1/4"	

