



Part Number	ESM Order Ref.	Illus No.	Description	Remarks
			Carburettor S.U. H1 Type 30° semi-down draught 1 1/8"	
CRB101	CRB101SH	-	Carburettor assembly	
CRB102	CRB102	1	Needle - GG	
CRB103	CRB103SH	2	Body	
CRB104	CRB104	3	Pin -piston lifting	
CRB105	CRB105	4	Circlip - lifting pin	
CRB106	CRB106	5	Spring - lifting pin	
CRB107	CRB107SH	6	Chamber and piston assembly - suction	
CRB108	CRB108	7	Cap assembly	
CRB110	CRB110	9	Screw to body	
CRB111	CRB111	10	Jet assembly	
CRB112	CRB112	11	Nut - adjusting	
CRB113	CRB113	12	Spring - adjusting	
CRB114	CRB114	13	Nut - gland sealing	
CRB115	CRB115	14	Ring - sealing	
CRB116	CRB116	15	Ring - sealing - cork	
CRB117	CRB117	16	Washer - bottom bearing	
CRB118	CRB118	17	Bearing - bottom	
CRB119	CRB119	18	Washer - gland - cork	
CRB120	CRB120	19	Washer - gland - brass	
CRB121	CRB121	20	Spring - gland	
CRB122	CRB122	21	Bearing - top	
CRB123	CRB123	22	Washer - top bearing	
CRB124	CRB124	23	Screw - needle locking	
CRB125	CRB125	24	Lever - jet	
CRB126	CRB126	25	Spring - lever return	
CRB127	CRB127	26	Link - lever to body	
CRB128	CRB128	27	Pin - link to body	
CRB128	CRB128	28	Pin - link to lever	
CRB128	CRB128	29	Pin - lever	
CRB129	CRB129	30	Split pin	
CRB130	CRB130	31	Screw - link clamp	
CRB131	CRB131	32	Washer - spring - 3/16"	
CRB132	CRB132	33	Nut - 2BA - locking	
CRB133	CRB133SH	34	Link - jet lever to rocker lever	
CRB134	CRB134	35	Spindle - throttle	
CRB135	CRB135	36	Disc	
CRB136	CRB136	37	Screw for disc	
CRB137	CRB137SH	38	Lever - throttle stop	
CRB138	CRB138	39	Pin - lever to spindle	
CRB139	CRB139	40	Screw - stop lever adjusting - long	
CRB140	CRB140	41	Spring - stop screw - long	
CRB142	CRB142	43	Screw - stop lever adjusting - short	
CRB143	CRB143	44	Spring - stop screw - short	
CRB144	CRB144	45	Bolt - lever clamping	
CRB131	CRB131	46	Washer	
CRB132	CRB132	47	Nut	
CRB145	CRB145	48	Lever - rocker	
CRB146	CRB146	49	Bolt	
CRB147	CRB147	50	Washer	
CRB148	CRB148	51	Washer	
CRB149	CRB149	52	Float chamber	
CRB150	CRB150	53	Bolt	
CRB151	CRB151	54	Washer	
CRB152	CRB152	55	Float	
CRB153	CRB153	56	Lid	
CRB154	CRB154	57	Gasket for lid	
CRB155	CRB230	58	Needle and seat assembly	
CRB156	CRB156	59	Lever - hinged	
CRB157	CRB157	60	Pin	
CRB158	CRB158	61	Filter	
CRB159	CRB159	62	Bolt - banjo	
CRB160	CRB160	63	Washer	
CRB161	CRB161	64	Cap nut - lid	
CRB162	CRB162	65	Cover - lid - brass	
CRB163	CRB163	66	Arm - float chamber support	
CRB166	CRB166	70	Gasket	
CSK40	CSK40	-	Service kit	
CRK226	CRK226	-	Rebuild kit	