



Part Number	ESM Order Ref.	Illus No.	Description	Remarks
			Carburetter - H2 - for use with 948cc engines from engine 9M/U/H101 to 165937	
CRB167	CRB167SH	1	Carburetter assembly	
CRB168	CRB168SH	2	Body assembly	
CRB104	CRB104	3	Pin	
CRB106	CRB106	4	Spring	
CRB105	CRB105	5	Circlip	
CRB169	CRB169SH	6	Chamber and piston assembly	
CRB170	CRB170SH	7	Screw - needle locking	
CRB108	CRB108	8	Cap and damper	
CRB171	CRB171	9	Washer	
CRB172	CRB172	10	Spring - piston -red	
CRB173	CRB173	11	Washer - thrust - spring	
CRB110	CRB110	12	Screw	
CRB111	CRB111	13	Jet	
CRB112	CRB112	14	Nut - adjusting	
CRB113	CRB113	15	Spring - adjusting nut	
CRB114	CRB114	16	Nut - gland sealing	
CRB115	CRB115	17	Ring - sealing	
CRB116	CRB116	18	Ring - sealing - cork	
CRB117	CRB117	19	Washer - bottom bearing	
CRB118	CRB118	20	Bearing - bottom	
CRB119	CRB119	21	Washer - gland - cork	
CRB120	CRB120	22	Washer - gland - brass	
CRB121	CRB121	23	Spring	
CRB122	CRB122	24	Bearing - top	
CRB123	CRB123	25	Washer - top bearing	
CRB174	CRB174	26	Needle - jet - standard (BX1)	
CRB175	CRB175	26	Needle - jet - weak (MO)	
CRB176	CRB176	27	Lever - jet	
CRB126	CRB126	28	Spring	
CRB177	CRB177SH	29	Link assembly - jet lever	
CRB130	CRB130	30	Bolt	
CRB132	CRB132	31	Nut	
CRB128	CRB128	32	Pin - link to body	
CRB128	CRB128	33	Pin - link to lever	
CRB179	CRB179	33	Pin - lever to jet	
CRB180	CRB180	35	Pin	
CRB181	CRB181	36	Washer	
CRB182	CRB182	38	Cam - slow running	
CRB146	CRB146	39	Bolt - pivot	
CRB147	CRB147	40	Spring washer	
CRB148	CRB148	41	Washer	
CRB185	CRB185	42	Spindle - throttle	
CRB186	CRB186	43	Disc - throttle	
CRB136	CRB136	44	Screw - disc	
CRB139	CRB139	46	Screw - stop adjusting	
CRB140	CRB140	47	Spring - screw	
CRB138	CRB138	48	Pin - taper	
CRB187	CRB187	49	Lever - throttle	
CRB188	CRB188	50	Bolt - lever	
CRB189	CRB189	51	Nut	
CRB190	CRB190	52	Chamber - float	
CRB150	CRB150	53	Bolt - float chamber to body	
CRB151	CRB151	54	Washer - fibre	
CRB191	CRB191	55	Lid - float chamber	
CRB192	CRB192	56	Lid - float chamber	
CRB193	CRB193	57	Washer - lid	
CRB230	CRB230	58	Needle and seat	
CRB195	CRB195	59	Lever - hinged	
CRB195	CRB196	60	Lever - hinged	
CRB157	CRB157	61	Pin - hinged	
CRB197	CRB197	62	Float	
CRB161	CRB161	63	Nut - cap	
CRB159	CRB159	65	Bolt - banjo	
CRB160	CRB160	66	Washer - fibre	
CRB198	CRB198	67	Nozzle - inlet	
CRB160	CRB160	68	Washer - fibre	
CRB158	CRB158	69	Filter	
CRB110	CRB110	70	Screw - support arm	