



Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
<i>Single carburetter - HS2 - for use with 1098cc engines No. 10V/189E/H301 on 10V/190E/H401 on</i>				
CRB246	CRB242B	1	Carburetter assembly	
CRB247	CRB247SH	2	Body	
CRB214	CRB214SH	3	Pin - piston lifting	
CRB106	CRB106	4	Spring - pin	
CRB105	CRB105	5	Circlip - pin	
CRB169	CRB169SH	6	Chamber and piston assembly	
CRB170	CRB170SH	7	Screw - needle locking	
CRB244	CRB108	8	Cap and damper	
CRB171	CRB171	9	Washer - fibre	
CRB199	CRB199	10	Screw - chamber to body	
CRB245	CRB245	11	Jet assembly	
CRB216	CRB216	16	Bearing - jet	
CRB217	CRB217	17	Washer - jet bearing (brass)	
CRB218	CRB218	18	Screw - jet locking	
CRB113	CRB113	19	Spring - jet locking	
CRB219	CRB219	20	Screw - jet adjusting	
CRB172	CRB172	21	Spring - piston -red	
CRB205	CRB205	22	Needle - jet - rich (HC)	
CRB221	CRB221	22	Needle - jet - standard (AN)	
CRB204	CRB204	22	Needle -jet - weak (EB)	
CRB223	CRB223	23	Lever - throttle return	
CRB251	CRB251	24	Lever - cam	
CRB225	CRB225SH	25	Chamber - float	
CRB226	CRB226SH	26	Bolt - float chamber fixing	
CRB227	CRB227	27	Float	
CRB157	CRB157	28	Pin - hinge	
CRB228	CRB228	29	Lid - float chamber	
CRB229	FUL133	30	Washer - lid	
CRB230	CRB230	31	Needle and seat	
CRB110	CRB110	32	Screw - lid	
CRB231	CRB231	33	Plate - baffle	
CRB232	CRB232	34	Spindle - throttle	
CRB186	CRB186	35	Disc - throttle	
CRB136	CRB136	36	Screw - disc	
CRB233	CRB233	37	Screw - stop	
CRB140	CRB140	38	Spring - screw	
CRB207	FIX130	39	Nut - 1/4" BSF	
CRB252	CRB252	40	Washer - tab	
CRB233	CRB233	41	Screw - throttle stop	
CRB140	CRB140	42	Spring - screw	
CRB253	CRB253	43	Washer - cam lever	
CRB254	CRB254	44	Spring - cam lever	
CRB236	CRB236	45	Bolt - pivot	
CRB237	CRB237	46	Tube - pivot bolt	
CRB238	CRB238	47	Washer - spring	
CRB255	CRB255SH	48	Lever and link - pick-up	
CRB241	CRB241	49	Spring - pick-up lever	