



Part Number	ESM Order Ref.	Illus. No.	Description	Remarks
<b>Gearbox - 948 cc</b>				
9G103	10G103	3	Plug - oil filler	
9G104	10G103	4	Plug - oil drain	
9G105	10G105	5	Reverse plunger	
9G106	10G107	6	Stud - front cover	
9G106	10G107	7	Stud - side cover	
9G107	10G106	8	Washer - reverse plunger	
9G108	9G108	9	Dowel - gearbox to mounting plate	
9G109	10G110	10	Fork - reverse	
9G110	9G110SH	11	Rod - reverse fork	
9G111	9G111	12	Fork - 1st and 2nd speed	
9G112	9G112SH	13	Rod - 1st and 2nd speed fork	
9G113	9G113	14	Fork - 3rd and 4th speed	
9G114	9G114SH	15	Rod - 3rd and 4th speed fork	
9G115	9G115	16	Screw - fork locating	
9G116	FIX156	17	Washer - spring - 1/4"	
9G117	FIX137	18	Nut - 1/4" UNF	
9G118	10G119	19	Screw - locking - reverse shaft	
9G119	FIX156	20	Washer - spring - 1/4"	
9G120	10G121	21	Plunger - interlocking	
9G121	10G122	22	Ball - interlocking	
9G122	10G123SH	23	Plug - interlocking - ball hole	
9G123	10G106	24	Washer - fibre	
9G124	10G121	25	Plunger - fork rods	
9G125	10G126	26	Spring - plunger	
9G126	10G127SH	27	Cover - side	
9G127	10G128	28	Gasket - side cover	
9G128	FIX156	29	Washer - spring - 1/4"	
9G129	FIX137	30	Nut - 1/4" UNF	
9G130	9G130	31	Cover - front - RHD	
9G131	9G131	32	Cover - front - LHD	
9G132	9G132	33	Gasket - front cover	
9G133	FIX157	34	Washer - spring - 5/16"	
9G134	FIX137	35	Nut - 1/4" UNF	
9G135	9G135	36	Lever - clutch withdrawal	
9G136	FIX120	37	Bush - lever	
9G137	FIX119	38	Bolt - clutch withdrawal lever	
9G138	FIX157	39	Washer - spring - 5/16"	
9G139	9G139SH	40	Washer - lock	
9G140	FIX139	41	Nut - 5/16" UNF	
9G141	10G261	42	Cover - clutch withdrawal lever	
9G142	10G262	43	Cover - dust - blanking	
9G143	10G136SH	44	Cover - starter pinion	
9G144	10G137	45	Screw	
9G145	FIX145	46	Washer - spring - 1/4"	