



<b>Part Number</b>	<b>ESM Order Ref.</b>	<b>Illus. No.</b>	<b>Description</b>	<b>Remarks</b>
10G102	10G102SH	2	Case assembly	
10G103	10G103	3	Plug - oil filler	
10G103	10G103	4	Plug - oil drain	
10G105	10G105SH	5	Plug - reverse plunger	
10G106	10G106	6	Washer - plug	
10G107	10G107	7	Stud - front cover	
10G108	10G107	8	Stud - side cover	
10G109	10G109	9	Dowel	
10G110	10G110	10	Fork - reverse	
10G111	10G111	11	Rod - reverse fork	
10G112	10G112	12	Fork - first and second speed	
10G113	10G113SH	13	Rod - first and second speed fork	
10G114	10G114	14	Fork - third and fourth speed	
10G115	10G115	15	Rod - third and fourth speed fork	
10G116	10G116	16	Screw - fork locating	
10G117	FIX156	17	Washer - shakeproof - 1/4"	
10G118	FIX137	18	Nut - 1/4" UNF	
10G119	10G119	19	Screw - locking - reverse shaft	
10G120	FIX156	20	Washer - spring - 1/4"	
10G121	10G121	21	Plunger - interlocking	
10G122	10G122	22	Ball - interlocking	
10G123	10G123SH	23	Plug - interlocking - ball hole	
10G124	10G106	24	Washer - plain	
10G125	10G125SH	25	Plunger - fork end	
10G126	10G126	26	Spring - plunger	
10G127	10G127SH	27	Cover - side	
10G128	10G128	28	Gasket - side cover	
10G129	FIX156	29	Washer - spring - 1/4"	
10G130	FIX137	30	Nut - 1/4" UNF	
10G131	10G131	31	Cover - front - RHD - with oil seal modification	
10G132	10G132	32	Cover - front - LHD - with oil seal modification	
10G133	22G165	33	Gasket	
10G134	FIX137	34	Nut - 1/4" UNF	
10G135	FIX156	35	Washer - spring - 1/4"	
10G136	10G136SH	36	Cover - starter pinion	
10G137	10G137	37	Screw	
10G138	FIX156	38	Washer - spring - 1/4"	
10G300	22G166	-	Lever - clutch withdrawal	